


Conexões em Latão (Material Latão Niquelado)




BSP	H	T
EF 5/16-02G	5/16"	1/4"
EF 5/16-01G	5/16"	1/8"
EF 3/8-02G	3/8"	1/4"
EF 5/16-03G	5/16"	3/8"
EF 3/8-03G	3/8"	3/8"
EF 5/16-04G	5/16"	1/2"
EF 3/8-04G	3/8"	1/2"
EF 1/2-04G	1/2"	1/2"
EF 5/8-04G	5/8"	1/2"
EF 3/4-04G	3/4"	1/2"



NPT	BSP	H	T
EM 3/16-01	EM 3/16-01G	3/16"	1/8"
EM 1/4-01	EM 1/4-01G	1/4"	1/8"
EM 5/16-01	EM 5/16-01G	5/16"	1/8"
EM 3/8-01	EM 3/8-01G	3/8"	1/8"
EM 1/2-01	EM 1/2-01G	1/2"	1/8"
EM 1/4-02	EM 3/16-02G	3/16"	1/4"
EM 1/4-02	EM 1/4-02G	1/4"	1/4"
EM 5/16-02	EM 5/16-02G	5/16"	1/4"
EM 3/8-02	EM 3/8-02G	3/8"	1/4"
EM 1/2-02	EM 1/2-02G	1/2"	1/4"
EM 1/4-03	EM 1/4-03G	1/4"	3/8"
EM 5/16-03	EM 5/16-03G	5/16"	3/8"
EM 3/8-03	EM 3/8-03G	3/8"	3/8"
EM 1/2-03	EM 1/2-03G	1/2"	3/8"
EM 5/8-03	EM 5/8-03G	5/8"	3/8"
EM 1/4-04	EM 1/4-04G	1/4"	1/2"
EM 3/16-04	EM 3/16-04G	3/16"	1/2"
EM 5/16-04	EM 5/16-04G	5/16"	1/2"
EM 3/8-04	EM 3/8-04G	3/8"	1/2"
EM 1/2-04	EM 1/2-04G	1/2"	1/2"
EM 5/8-04	EM 5/8-04G	5/8"	1/2"
EM 3/4-04	EM 3/4-04G	3/4"	1/2"
EM 3/8-06	EM 3/8-06G	3/8"	3/4"
EM 1-06	EM 1-06G	1"	3/4"
EM 1-10	EM 1-10G	1"	1"
EM 3/4-10	EM 3/4-10G	3/4"	1"
EM 1/2-06	EM 1/2-06G	1/2"	3/4"
EM 5/8-06	EM 5/8-06G	5/8"	3/4"




NPT	BSP	T1	T2
NI 01-01	NI 01-01G	1/8"	1/8"
NI 02-01	NI 02-01G	1/4"	1/8"
NI 02-02	NI 02-02G	1/4"	1/4"
NI 03-01	NI 03-01G	3/8"	1/8"
NI 03-02	NI 03-02G	3/8"	1/4"
NI 03-03	NI 03-03G	3/8"	3/8"
NI 04-02	NI 04-02G	1/2"	1/4"
NI 04-03	NI 04-03G	1/2"	3/8"
NI 04-04	NI 04-04G	1/2"	1/2"
NI 06-04	NI 06-04G	3/4"	1/2"
NI 06-06	NI 06-06G	3/4"	3/4"




NPT	BSP	F	T
ADT 01-01	ADT 01-01G	1/8"	1/8"
ADT 02-01	ADT 02-01G	1/4"	1/8"
ADT 02-02	ADT 02-02G	1/4"	1/4"
ADT 03-01	ADT 03-01G	3/8"	1/8"
ADT 03-02	ADT 03-02G	3/8"	1/4"
ADT 03-03	ADT 03-03G	3/8"	3/8"
ADT 04-02	ADT 04-02G	1/2"	1/4"
ADT 04-03	ADT 04-03G	1/2"	3/8"
ADT 04-04	ADT 04-04G	1/2"	1/2"



BSP	T1	T2
LU 01-01G	1/8"	1/8"
LU 02-01G	1/4"	1/8"
LU 02-02G	1/4"	1/4"
LU 03-02G	3/8"	1/4"
LU 03-03G	3/8"	3/8"
LU 04-02G	1/2"	1/4"
LU 04-03G	1/2"	3/8"
LU 04-04G	1/2"	1/2"



NPT	BSP	F
PLU 01	PLU 01G	1/8"
PLU 02	PLU 02G	1/4"
PLU 03	PLU 03G	3/8"
PLU 04	PLU 04G	1/2"
PLU 06	PLU 06G	3/4"



NPT	BSP	F	T
BU 01-02	BU 01-02G	1/8"	1/4"
BU 01-03	BU 01-03G	1/8"	3/8"
BU 02-03	BU 02-03G	1/4"	3/8"
BU 02-04	BU 02-04G	1/4"	1/2"
BU 03-04	BU 03-04G	3/8"	1/2"
BU 03-06	BU 03-06G	3/8"	3/4"
BU 04-06	BU 04-06G	1/2"	3/4"
BU 06-10	BU 06-10G	3/4"	1"



BSP	ROSCA
LMF 01G	1/8"
LMF 02G	1/4"
LMF 03G	3/8"
LMF 04G	1/2"
LMF 06G	3/4"



BSP	ROSCA
PLUC 01G	1/8"
PLUC 02G	1/4"
PLUC 03G	3/8"
PLUC 04G	1/2"
PLUC 06G	3/4"
PLUC 10G	1"



BSP	ROSCA
LF 01G	1/8"
LF 02G	1/4"
LF 03G	3/8"
LF 04G	1/2"
LF 06G	3/4"



BSP	ROSCA
T 01G	1/8"
T 02G	1/4"
T 03G	3/8"
T 04G	1/2"
T 06G	3/4"